

FROM		ANGLE		DIST	NORTH	EAST	TO
PT/PT INVERSE		1A					
*****	START				615787.74365	2006227.66026	462
462	INV	N	89 39 48	E	1255.02	615795.11882	463
463	INV	S	0 56 19	W	24.97	615770.14922	464
464	INV	N	87 47 19	E	25.51	615771.13368	465
465	INV	S	1 39 10	E	488.74	615282.59943	466
466	INV	S	1 39 10	E	177.06	615105.61110	467
467	INV	S	89 39 48	W	1286.91	615098.04851	134
							calc
134	INV	N	1 01 48	W	689.81	615787.74365	462

615787.74365 2006227.66026 462

NO CLOSURE ERROR Area = 884455.92 sq ft 20.30431 ac

FROM		ANGLE		DIST	NORTH	EAST	TO
PT/PT INVERSE		2A					
*****	START				615098.04851	2006240.05882	134
							calc
134	INV	N	89 39 48	E	642.55	615101.82446	468
468	INV	S	0 49 28	E	339.24	614762.62410	469
469	INV	S	0 36 48	E	246.63	614516.01052	470
470	INV	S	1 47 09	E	344.37	614171.80871	471
471	INV	S	13 33 35	W	563.37	613624.14497	472
472	INV	S	0 28 13	E	220.00	613404.15238	481
481	INV	N	89 31 47	E	2.15	613404.17002	480
480	INV	S	0 28 13	E	220.00	613184.17743	479
479	INV	S	89 31 47	W	250.00	613182.12596	96
							calc
96	INV	N	0 53 24	W	440.01	613622.08469	95
							calc
95	INV	S	89 31 47	W	251.07	613620.02441	473
473	INV	N	1 01 48	W	1478.26	615098.04851	134

615098.04851 2006240.05882 134

NO CLOSURE ERROR Area = 1020613.40 sq ft 23.43006 ac